

ARNO ActiFry

P

ΕN







ARNO Nutritivo e Delicioso

Inovar para a sua saúde

A alimentação nutritiva é, evidentemente, comer de forma variada e equilibrada... mas não somente isso, já que a alimentação não se limita aos ingredientes. A forma como os cozinhamos desempenha um fator essencial na sua transformação nutricional (sabor, textura...).

Visto que nem todos os aparelhos são iguais, a **ARNO** desenvolveu uma linha dedicada à ALIMENTAÇÃO mais prazerosa: aparelhos inovadores que conservam a integridade nutritiva e que liberam o verdadeiro sabor dos ingredientes.

Apresentar soluções únicas

A **ARNO** investiu em pesquisas para criar aparelhos com desempenhos nutricionais únicos e comprovados por estudos científicos.

Informar

A ARNO é, uma aliada em sua alimentação, proporcionando-lhe rapidez, praticidade e facilidade no preparo das refeições. Dia após dia, a linha Nutritivo & Delicioso da ARNO irá ajudá-lo a compartilhar o prazer culinário e o equilibrio alimentar ao:

- favorecer e preservar as qualidades dos ingredientes naturais e essenciais para a sua alimentação,
- limitar a utilização de óleos e gorduras,
- favorecer a volta aos gostos e sabores esquecidos,
- limitar o tempo gasto na preparação de uma refeição.

Dentro desta linha de produtos, a ActiFry permite-lhe preparar 1 kg de autênticas batatas fritas com apenas uma colher do seu óleo preferido!

Bem-vindo ao universo ActiFry'!

Prepare autênticas e saborosas batatas fritas à sua maneira

As batatas fritas são crocantes por fora e macias graças à tecnologia patenteada: da pá que mistura e espalha o óleo de forma sutil ; e do sistema de circulação de ar aquecido . Selecione os ingredientes, o óleo, as especiarias, as ervas aromáticas, os aromatizantes...Actifry cuida do resto.

Apenas 3 %* de gordura: basta 1 colher de óleo!

Uma colher do óleo à sua escolha permite fritar 1 kg de autênticas batatas fritas. Graças à colher dosadora fornecida com o aparelho, utilize apenas a quantidade estritamente necessária.

* 1 kg de batatas fritas frescas, com medidas de 13x13 mm, fritura a -55 % de perda de peso com 14 ml de óleo.

Batatas fritas e muito mais!

ActiFry' permite-lhe cozinhar uma grande variedade de receitas.

 Além de batatas fritas e de batatás assadas, pode variar o seu dia-a-dia com legumes salteados, carnes saborosas, camarões crocantes e frutas.



Propomos um livro de receitas elaborado por grandes chefs e nutricionistas. Aqui encontrará ideias originais de "Batatas fritas à sua maneira", pratos saborosos e nutritivos e sobremesas.

 ActiFry cozinha igualmente bem os alimentos congelados, que são uma boa alternativa aos produtos frescos. São práticos, conservam as qualidades nutricionais e o sabor dos alimentos.

Para obter melhores resultados nas suas preparações, ActiFry¹ lhe da conselhos sobre batatas e óleos.

A batata: equilíbrio e prazer no dia-a-dia!

A batata pode ser consumida por todos e em todas as idades! É uma excelente fonte de energia e contém vitaminas. De acordo com as variedades, as condições climáticas e o cultivo, a batata passa por variações significativas: forma, tamanho, qualidade gustativa. Cada uma possui as suas características próprias de precocidade, rendimento, tamanho, cor, qualidade de conservação e indicações culinárias. Os resultados da fritura podem variar em função da origeme e da estacão.

Qual a variedade aconselhável para ActiFry ?

Em geral o aconselhamos a utilizar, as batatás especiais para fritura. Para as batatas novas ricas em umidade, o aconselhamos a fritar as batatas alguns minutos a mais. ActiFry permite ainda preparar batatas fritas congeladas. Dado que estas já são pré-fritas, não é necessário adicionar óleo.

Onde devo conservar as batatas?

Os melhores locais para a conservação das batatas são armários frescos (entre 6 e 8°C) e ao abrigo da luz. Como preparar as batatas para ActiFry ?

Para obter melhores resultados, é necessário garantir que as batatas fritas não ficam coladas umas às outras. Para tal, é aconselhável lavar com água em abundância as batatas inteiras e, só depois, as batatas cortadas, até que a água fique limpida. Eliminará, desta forma, o máximo possível de amido. Seque cuidadosamente as batatas fritas com a ajuda de um pano seco extremamente absorvente. As batatas fritas têm de estar totalmente secas antes de colocá-las na ActiFry.

Como se deve cortar as batatas?

O tamanho da batata frita influencia o aspecto crocante e o sabor. Quanto mais finas forem as suas batatas fritas, mais crocantes serão e vice-versa, ou seja, quanto mais grossas forem, mais macias serão no interior. De acordo com sua preferência, pode variar os cortes das batatas fritas e adaptar o tempo da fritura:

Finas: 8 x 8 mm/Média: 10 x 10 mm/Grossas: 13 x 13 mm

Varie os óleos saudáveis que fazem bem

Varie os sabores de acordo com suas preferências, usando apenas 1 colher de óleo (um cada preparação). Todos os ácidos graxos essenciais a saúde encontram-se nos óleos vegetais. Todos eles contêm, em proporções diferentes, nutrientes indispensáveis para o seu equilibrio. Para fornecer ao seu corpo tudo aquilo de que necessita, diversifique os óleos! Com ActiFry', é possível utilizar uma grande variedade de óleos:

- óleos comuns: oliva, colza*, de uva, milho, amendoim, girassol, soja*,
- óleos aromatizados: ervas aromáticas, alho, pimenta, limão...
- óleos especiais: noz *, sésamo*, cártamo*, amêndoa*, abacate*, argan*... (*fritura segundo indicação do fabricante).

A tecnologia ActiFry', com uma quantidade reduzida de óleo de uso único, permite-lhe conservar os ácidos graxos saudáveis, essenciais para a sua saúde.



Com Actifry e um óleo à escolha, obterá batatas fritas com uma melhor qualidade nutricional. De acordo com os seus gostos e suas expectativas, poderá sempre adicionar, mais 1 colher de óleo para um sabor ainda mais intenso!

Com ActiFry*, tenha prazer e dê prazer aos que o rodeiam!

Recomendações importantes

Instruções de segurança

- Leia estas instruções com atenção e quarde-as para futuras utilizações. Este aparelho n\u00e3o foi concebido par\u00e4 funcionar com um temporizador.
- externo ou com um sistema de comando à distância separado.
- Para a sua segurança, este aparelho está em conformidade com as normas e regulações vigentes (Diretrizes de Baixa Tensão, Compatibilidade Eletromagnética, Materiais compatíveis com os alimentos, Meio ambiente...).
- Certifique-se que a tensão da rede corresponde à indicada no aparelho (corrente alternada).
- Dada a diversidade das normas em vigor, se o aparelho for utilizado num país diferente daquele de procedência na aquisição, solicite a sua inspeção junto a um Serviço de Assistência Técnica Autorizado. • Este aparelho foi concebido apenas para uso doméstico. Qualquer utili-
- zação profissional, inadequada ou não conforme o manual de instruções libera o fabricante de qualquer responsabilidade e anula a garantia.

Ligação

- Não utilize o aparelho se ele ou o seu cabo de alimentação encontrarem-se de alguma forma danificados e, se o aparelho cair no chão e apresentar danos visíveis ou anomalias de funcionamento. Neste caso. o aparelho tem de ser enviado para um Serviço de Assistência Técnica Autorizado.
- Não utilize uma extensão. Caso assuma a responsabilidade de utilizar uma extensão, certifique-se que se encontra ém perfeito estado de funcionamento e que se adapte à potência do aparelho.
- Se o cabo de alimentação se encontrar de alguma forma danificado deve ser substituído pelo fabricante ou por, um Serviço de Assistência Técnica Autorizado de forma a evitar qualquer situação de perigo para o utilizador. Nunca desmonte o aparelho pelos seus próprios meios.
- Não deixe o cabo de alimentação pendurado.
- Não desligue o aparelho puxando pelo cabo.
 Desligue sempre o aparelho após cada utilização, para o deslocar ou para o procedimento de limpeza.

Funcionamento

- Utilize uma superfície de trabalho estável, plana e distante de água.
- Este aparelho não foi concebido para ser utilizado por pessoas (incluindo crianças) cujas capacidades físicas, sensoriais ou mentais se encontram reduzidas, ou por pessoas com falta de experiência ou conhecimento, a não ser que tenham sido devidamente acompanhadas e instruídas sobre a correta utilização do aparelho, pela pessoa responsável pela sua segurança.
- É importante vigiar as crianças de forma a garantir que as mesmas não brinquem com o aparelho.
- Nunca deixe o aparelho funcionar sem vigilância. Mantenha-o fora do alcance das crianças.
- A temperatura das superfícies pode ser alta durante o funcionamento do aparelho, o que pode causar queimaduras. Não toque nas superficies quentes do aparelho (tampa, peças de metal visíveis...)
- Não coloque o aparelho em funcionamento na proximidade de materiais inflamáveis nem na proximidade de uma fonte de calor externa (bico de gás, placa de aquecimento...).
 • No caso de incêndio, nunca tente apagar as chamas com água. Apa-
- que-as com um pano úmido.
- Não desloque o aparelho com alimentos quentes no seu interior.
- Nunca mergulhe o aparelho em água!



Cozimento

- Este aparelho não foi concebido para a preparação de receitas líquidas (sopas...).
- Nunca coloque o aparelho a funcionar vazio.
- Não encha excessivamente a cuba, respeite as quantidades recomendadas.

Descrição

- Zona de contato da tampa
- 2. Tampa transparente
- 3. Sistema de trava da tampa
- 4. Colher dosadora
- Abas de bloqueio/desbloqueio da pá (cor cinza claro)
- Nível máximo de enchimento (para batatas fritas)
- Pá de mistura removível
- 8. Cuba removível
- Botão de desbloqueio do cabo

- 10. Cabo da cuba
- 11. Base
- 12. Filtro removível
- 13. Comandos de abertura da tampa
- 14. Temporizador
- Botão Ligar/Desligar
 (On = Ligar, Off = Desligar)
- Botão de regulagem do temporizador
- Painel de comando desmontável (acesso ao compartimento da pilha)

Uma preparação rápida

Antes da primeira utilização

- Abra a tampa fig. 1 e levante o sistema de trava para retirar a tampa - fig. 2.
- Retire a colher dosadora.
- Levante a pega da cuba removível na horizontal até ouvir um "CLIQUE", para retirar a cuba - fig. 3.
- Retire a pá levantando as abas de bloqueio: apoiar o polegar sobre a parte superior da pá e colocar o indicador e o dedo maior por baixo das abas de bloqueio - fig. 4a.
- Todas as pecas removíveis podem ser lavadas na máquina de lavar louça - fig. 5 ou podem ser lavadas com uma esponja não-abrasiva e detergente para a louça.
- e Limpe a base do aparelho com uma esponja úmida e detergente para a louça.
- Secár cuidadosamente antes de voltar a colocar todos os elementos no respectivo lugar.
 Para fixar a pá puxe para cima as abas de bloqueio, posicione a pá no centro da cuba e pressione as abas - fig. 4b.
- entro da cuale pressione as adas 19, 30.
 No decorrer da primeira utilização, pode-se notar a emissão de odor inofensivo. Este fenômeno não possui consequências para a utilização do aparelho e desaparecerá rapidamente.

Retire todos os adesivos e elementos da embalagem. Nunca passe o aparelho por água.

Durante a primeira utilização e para obter os melhores resultados, aconselhamos a proceder a um primeiro cozimento durante pelo menos 30 minutos.

- Prepare os alimentos

Para as batatas fritas, nunca ultrapasse o nível máximo indicado na pá removível - fig. 6. Não deixe a colher dosadora na cuba Coloque os alimentos na cuba e respeite a quantidade máxima
 (consulte o quadro de cozimento da p. 8 à 9)

(consulte o quadro de cozimento da p. 8 à 9).

• Adicione o óleo - fig. 7 (consulte o quadro de cozimento da p. 8 à 9).

 Desbloqueie o cabo e abaixe-o por completo no respectivo compartimento - fig. 8.

Feche a tampa - fia. 9.

Um cozimento rápido

Selecione o tempo de cozimento –

- Ajuste o tempo apertando o botão do temporizador fig. 10 (consulte o quadro do cozimento da p. 8 à 9).
- Solte. É exibido o tempo selecionando e inicia-se a contagem decrescente.
- No caso de erro ou para apagar o período de tempo selecionado, mantenha o botão pressionado durante 2 segundos e selecione novamente o período de tempo pretendido.

Atenção: o temporizador indica o fim do tempo do cozimento mas não pára o aparelho.

Pressione o botão Ligar/Desligar. O cozimento começa graças à circulação de ar quente no compartimento do cozimento - fig. 11.

Retire os alimentos -

- Quando o cozimento terminar, o temporizador emite um sinal sonoro.
 Deslique o alarme pressionando o botão fig. 12.
- Desligue o aparelho apertando o botão Ligar/Desligar fig. 13 e abra a tampa - fig. 1.
- Levante o cabo e retire a cuba fig. 14 .Sirva em seguida.

Os tempos de cozimento

Os tempos de cozimento são fornecidos a título indicativo. Podem variar em função do estado dos alimentos, do seu tamanho, das quantidades, do gosto de cada pessoa e da tensão da rede elétrica. A quantidade de óleo indicada pode ser aumentada em função dos seus gostos e das suas necessidades. Caso deseje obter batatas fritas ainda mais crocantes, poderá sempre acrescentar alguns minutos de cozimento suplementar.

Batatas -

| | TIPO | QUANTIDADE | ADICIONAR | TEMPO DE COZIMENTO |
|------------------------------------|------------|------------|--------------------|-----------------------|
| | Frescas | 1000 g | 1 colher de óleo | 40 - 45 min |
| Batatas fritas Tamanho standard | Frescas | 750 g | 3/4 colher de óleo | 35 - 37 min |
| 10mm x10mm | Frescas | 500 g | 1/2 colher de óleo | 28 - 30 min |
| | Frescas | 250 g | 1/4 colher de óleo | 24 - 26 min |
| Batatas assadas | Frescas | 1000 g | 1 colher de óleo | 40 - 42 min |
| Batatas assadas | Congeladas | 750 g | nada | 14 - 16 min |
| Batatas salteadas | Frescas | 1000 g | 1 colher de óleo | 40 - 42 min |
| Batatas saiteadas | Congeladas | 750 g | nada | 30 - 32 min |
| Batatas fritas em rodelas | Congeladas | 750 g | nada | 30 - 32 min |
| Batatas fritas palitos | Congeladas | 750 g | nada | 25 - 27 min |

Outros legumes

| | TIPO | QUANTIDADE | ADICIONAR | TEMPO DE COZIMENTO |
|-----------|---------------------|------------|--------------------------------------|-----------------------|
| Abobrinha | Frescas em tiras | 750 g | 1 colher de óleo + 150 ml de água | 25 - 35 min |
| Pimentões | Frescos em tiras | 650 g | 1 colher de óleo + 150 ml de água | 20 - 25 min |
| Cogumelos | Frescos aos quartos | 650 g | 1 colher de óleo | 12 - 15 min |
| Tomates | Frescos aos quartos | 650 g | 1 colher de óleo + 150 ml de água | 10 - 15 min |
| Cebolas | Frescos aos quartos | 500 g | 1 colher de óleo | 15 - 25 min |

Carnes - Aves -

Para adicionar sabor às suas carnes, não hesite em misturar especiarias no óleo (paprika, curry, ervas de Provença, tomilho, louro ...)

| | TIPO | QUANTIDADE | ADICIONAR | TEMPO DE COZIMENTO |
|------------------------|------------|---------------------------|------------------------------|-----------------------|
| Nonesta de ferra | Frescos | 750 g | nada | 18 - 20 min |
| Nuggets de frango | Congelados | 750 g | nada | 18 - 20 min |
| Sobre coxas de frango | Frescas | 4α6 | nada | 30 - 32 min |
| Coxas de frango | Frescas | 2 | nada | 30 - 35 min |
| Peitos de frango | Frescos | 6 peitos (cerca de 750 g) | nada | 10 - 15 min |
| Rolinho primavera | Frescos | 4 α 8 pequenos | 1 colher de óleo | 10 - 12 min |
| Rolinhos de vitela | Frescos | 2α6 | 1 colher de óleo | 15 - 20 min |
| Costeletas de cordeiro | Frescas | 2α6 | 1 colher de óleo | 15 - 20 min |
| Costeletas de porco | Frescas | 2α4 | 1 colher de óleo | 15 - 18 min |
| Lombo de porco | Frescos | 2 a 6 fatias | 1 colher de óleo | 12 - 15 min |
| Salsichas frescas | Frescas | 4 a 8 (picadas) | nada | 10 - 12 min |
| Lombo de coelho | Fresco | 2 a 6 unidades | 1 colher de óleo | 15 - 20 min |
| Company | Fresca | 600 g | 1 colher de óleo | 10 - 15 min |
| Carne picada | Congelada | 400 g | nada ou com 1 colher de óleo | 12 - 15 min |
| Almôndegas de carne | Congeladas | 750 g | 1 colher de óleo | 18 - 20 min |

Peixes - Crustáceos

| | TIPO | QUANTIDADE | ADICIONAR | TEMPO DE COZIMENTO |
|----------|------------|---------------------|------------------|-----------------------|
| Lula | Congelados | 300 g | nada | 12 - 14 min |
| Rã | Fresca | 500 g | 1 colher de óleo | 20 - 22 min |
| Camarões | Cozidos | 400 g | nada | 10 - 12 min |
| Camarões | Congelados | 300 g (16 unidades) | nada | 12 - 14 min |

Sobremesas

| | TIPO | QUANTIDADE | ADICIONAR | TEMPO DE COZIMENTO |
|----------|---------------------|-------------------|---|-----------------------|
| Bananas | em rodelas | 500 g (5 bananas) | 1 colher de óleo +1 colher de açúcar mascavo | 4 - 6 min |
| | em papillotes | 2 bananas | nada | 20 - 25 min |
| Cerejas | Inteiras | até 1000g | 1 colher de óleo + 1 a 2 colheres de açúcar | 12 - 15 min |
| Morangos | cortados em quartos | até 1000g | 1 a 2 colheres de açúcar | 5 - 7 min |
| Maçãs | cortadas ao meio | 3 | 1 colher de óleo + 1 a 2 colheres de açúcar | 10 - 12 min |
| Pêras | cortadas em pedaços | até 1000g | 1 a 2 colheres de açúcar | 8 - 12 min |
| Abacaxi | cortado em pedaços | 1 | 1 a 2 colheres de açúcar | 8 - 12 min |

Preparações congeladas

| | TIPO | QUANTIDADE | ADICIONAR | TEMPO DE COZIMENTO |
|-------------------|------------|------------|-----------|-----------------------|
| Ratatouille | Congelado | 750 g | nada | 20- 22 min |
| Massa de peixe | Congelada | 750 g | nada | 20 - 22 min |
| Legumes salteados | Congelados | 750 g | nada | 25 - 30 min |
| Massa a carbonara | Congelada | 750 g | nada | 20 - 25 min |
| Paella | Congelada | 650 g | nada | 15 - 20 min |
| Arroz cantonês | Congelado | 650 g | nada | 15 - 20 min |
| Chili com Carne | Congelado | 750 g | nada | 12 - 15 min |

Fácil limpeza

Limpe o aparelho

- Deixe-o esfriar completamente antes de limpá-lo.
 Abra a tampa fig. 1 e levante o sistema de trava para retirar a tampa fig. 2.
- Levante o cabo da cuba removível na horizontal até ouvir um "CLIQUE" e retire a cuba - fig. 3.
- Retire a pá levantando as abas de bloqueio fig. 4a.
 Retire o filtro removível e limpe-o fig.3.
- Todas as pecas removíveis podem ser lavadas na máquina de lavar louça 119.5 o u podem ser lavadas com uma esponja não abrasiva e detergente para a louça.
- Limpe o corpo do aparelho com uma esponja úmida e detergente para
- Segué cuidadosamente antes de voltar a colocar todos os elementos no respectivo lugar.
- O aparelho está equipado com uma cuba removível: o escurecimento e os riscos que podem aparecer na sequência de uma longa utilização não constituem qualquer tipo de inconveniente.
- Garantimos que a cuba está EM CONFORMIDADE COM A REGULA-MENTAÇÃO referente aos materiais em contato com os alimentos.

- Nunca mergulhe o aparelho em água. Não utilize produtos de manutenção agressivos ou abrasivos.
- O filtro removível deve ser retirado e limpo regular-
- Para conservar por mais tempo as qualidades da cuba, não utilize qualquer utensílio de metal.

Alguns conselhos no caso de dificuldades...

| PROBLEMAS | CAUSAS | SOLUÇÕES |
|---|--|---|
| O aparelho não funciona. | O aparelho não se encontra corretamente ligado. | Certifique-se que o aparelho se encontra corretamente ligado. |
| | Não apertou o botão Ligar/Desligar. | Pressione o botão Ligar/Desligar. |
| | Pressionou o botão Ligar/Desligar mas o aparelho não funciona. | Feche a tampa. |
| | Os motores estão funcionando mas o aparelho não aquece. | Leve o aparelho a um Serviço de Assistência Técnica Autorizado. |
| | A pá não gira. | Certifique-se que a pá está no devido lugar; se persistir, leve o aparelho a um Serviço de Assistência Técnica Autorizado. |
| A pá não fica fixa | A pá não se encontra corretamente afixada. | Para fixar novamente a pá, puxe para cima as abas de bloqueio, posicione a pá no centro da cuba e pressione as abas. |
| O cozimento das preparações não é homogêneo. | Não utilizou a pá. | Coloque-a no lugar. |
| e nomogeneo. | Os alimentos não foram cortados de forma regular. | Corte os alimentos todos do mesmo tamanho. |
| | As batatas fritas não foram cortadas de forma regular. | Corte as batatas fritas todas do mesmo tamanho. |
| | A pá está devidamente colocada mas não gira. | Leve o aparelho a um Serviço de Assistência Técnica Autorizado. |
| As batatas fritas não estão suficientemente crocantes. | Você não utiliza batatas especiais para batatas fritas. | Escolha batatas especiais para batatas fritas. |
| | As batatas não estão suficientemente lavadas e secas. | Lave, escorra e seque bem as batatas antes da fritura. |
| | As batatas fritas estão grossas demais. | Corte-as mais finas. |
| | Quantidade de óleo insuficiente. | Aumente a quantidade de óleo (consulte o quadro da fritura, p. 8 a 9). |
| | O filtro está obstruído. | Limpe o filtro removível. |
| As batatas fritas partem-se no decorrer da fritura. | Utilizou batatas novas. | Reduza a quantidade de batatas para 750 g e adapte o tempo de fritura. |
| Os alimentos ficam colados nas paredes da cuba. | A cuba está cheia demais. | Respeite as quantidades indicadas no quadro de cozimento. |
| Escorreram líquidos de cozimento para a base do aparelho. | A pá está mal posicionada ou a junta da pá está defeituosa | Certifique-se que a pá se encontra corretamente posicionada. No caso de persistência do problema, leve o aparelho a um Serviço de Assistência Técnica Autorizado. |
| O temporizador não funciona. | A pilha está gasta. | Substitua a pilha (consulte a fig. 15). |
| O aparelho emite um ruído anormal. | Suspeita de uma anomalia no funcionamento dos motores do aparelho. | Leve o aparelho a um Serviço de Assistência Técnica Autorizado. |

Proteção do meio ambiente em primeiro lugar!

Este aparelho utiliza uma pilha de botão - L1154.

- Para a substituir abra o painel de comando, retire a tampa do compartimento da pilha e, em seguida,
 a pilha fig. 15. Por respeito ao meio ambiente, não descarte fora a pilha gasta juntamente com o modo
 doméstico mas leve-a para um ponto de coleta previsto para este fim.
- Insira uma pilha nova, volte a colocar a tampa e fixe de novo o painel de comando.
 O seu aparelho contém materiais que podem ser recuperados ou reciclados.





ALERTA AO CONSUMIDOR: caso você, após ter lido o manual de instruções, ainda tenha dúvidas quanto à utilização deste ou de qualquer outro produto ARNO, ou caso tenha sugestões, entre em contato com a ARNO através do SAC 0800 0119933 (ligação gratuita) ou visite nosso site - www.arno.com.br - e envie um e-mail

Veja mais dicas no nosso site - www.arno.com.br

As características gerais do produto podem sofrer alterações sem aviso prévio.

ARNO Nutritious & Delicious

Innovating for your health's sake

Nutrition is about having a varied and well balanced diet... however it is also about far more than just the ingredients. How they are prepared and cooked can significantly affect their nutritional value, and have a major impact on their taste and texture.

Nutrition is therefore also about the differences in composition between the many preparation methods and cooking appliances available today. With this in mind, ARNO has developed a specific range of appliances that are dedicated to NUTRITION FOR GREATER PLEASURE: ingenious culinary appliances which preserve the nutritional integrity and enhance the true taste of the ingredients. Bringing you unique solutions

ARNO invests in research to bring you unique solutions with nutritional benefits that are validated by scientific studies.

Informing you

For many years **ARNO** has been bringing you appliances which help in the preparation of your meals by providing speed, convenience and ease of use. Each day, the **ARNO** Nutritious and Delicious range will help you by:

- preserving the quality of the natural ingredients that are essential to your diet,
- · limiting the use of fat,
- · rediscovering the natural tastes and flavours of food,
- reducing the time spent on the preparation of meals.

Within this range of products, ActiFry' enables you to prepare 1 kg of potatoes into homemade chips with just 1 spoonful (14 ml) of your favourite oil!

Welcome to the world of ActiFry !

Make real tasty chips just the way you like them!

ActiFry' chips are delicious with a crispy coating on the outside and soft and tender inside thanks to the patented technologies: the stirring paddle which gently mixes the food and evenly disperses the oil, and the unique warm air heating system. Choose your ingredients, oil, spices, herbs and seasonings...and let ActiFry take care of the rest.

Only 3% fat*: 1 spoonful (14ml) of oil is enough!

One spoonful of the oil of your choice allows you to make real chips from 1kg of potatoes. You can be sure of using exactly the right amount, thanks to the graduated spoon that is supplied with the appliance. *1 kg of potatoes prepared then cut into fresh chips, to a thickness 13x13 mm and a length of up to approx 9cm, cooked until -55% of weight loss with 14 ml of oil..

Chips and so much more!

ActiFry' enables you to cook a wide variety of recipes.

 In addition to chips and potatoes, you can vary your meals with stir fry cooked vegetables, tender and succulent minced meat dishes, meatballs and crispy fried prawns, shellfish and fruit.



 The + ActiFry cooks frozen food very well too. Frozen foods are a good alternative to fresh products. They are practical and conserve the products' nutritional qualities and taste.

For the best results with your ActiFry , we advise following our recommendations on the type of potatoes and oil to use.

The potato: balance and pleasure on a daily basis!

Potatoes are an excellent source of energy and contain vitamins. Potatoes vary enormously in size, shape and taste according to the variety, climate and growing conditions. Each variety has its particular cropping time, yield, size, colour, keeping quality and culinary uses. A potato's characteristics when cooked may vary according to its origin and seasonality.

Which variety should I use?

As a general rule, we suggest that you use special potatoes that have been recommended for chipping. In many supermarkets the information on the packaging tells you which varieties are suitable for making chips. We recommend varieties such as King Edward and Maris Piper for good results.

When potatoes have been freshly harvested, they have a higher water content, we recommend cooking the chips for a few more minutes.

Where should I store potatoes?

The best place to store potatoes is in a dark cellar or cool cupboard (between 6 and 8°C), away from the light. How should I prepare potatoes for ActiFry'?

To obtain the best results, you must ensure that the chips do not stick together. With this in mind, wash the whole potatoes and then cut them into chips using a sharp knife or chip cutter. The chips should be of equal size so that they cook at the same time. Wash the chipped potatoes in pienty of cold water until it runs clear in order to remove as much of the starch as possible. Dry the chips thoroughly using a clean highly absorbent tea towel. The chips must be perfectly dry before putting them in the Actifry otherwise they will not turn crispy. To check that they are dry enough pat them with paper kitchen towel just before cooking. If there is any wetness on the paper dry them again. Remember the cooking time of the chips will vary according to the weight of chips and the batch of potatoes used.

How should I cut the potatoes?

The size of a chip influences how crunchy or soft it is. The thinner your chips, the more crunchy they will be and conversely, thicker chips will be softer inside. You can cut your chips to the following thickness and lenath according to your tastes:

Thickness: American style: 8 x 8mm / Thin: 10 x 10mm / Standard: 13 x 13mm

Length: Up to approx 9cm.

In Actifry the maximum recommended chip thickness is 13mm x 13mm and a length of up to 9cm.

Try a variety of different oils for good health

You can vary the type of oil depending on your choice with 1 ActiFry' spoonful of oil for 1 kg of potatoes. Choose a different oil every time you cook!

With ActiFry', you can use a very wide variety of oils:

- · Standard oils: olive oil, grape seed oil, corn oil, groundnut (peanut) oil, sunflower oil, soya oil*
- Flavoured oils: oils infused with aromatic herbs, garlic, chilli, lemon...
- · Speciality oils: hazelnut*, sesame*...

(*cook according to the manufacturers instructions)

With its low quantity of oil for each use, the technology of ActiFry' helps in providing a healthier, nutritionally balanced diet.



With ActiFry', you can make chips with a better nutritional quality. For extra flavour, you can add 1 or 2 additional spoonfuls of oil for even more taste but this will increase the fat content.

With + ActiFry*, make tastier, healthier chips just as you like them!

Important recommendations

Safety instructions

• Read and follow the instructions for use. Keep them for future use.

 This appliance is not intended to be operated using an external timer or separate remote control system.

 For your safety, this appliance complies with the safety regulations and directives in effect at the time of manufacture (Low-voltage Directive, Electromagnetic Compatibility, Food Contact Materials Regulations, Environment...).

Check that the power supply voltage corresponds to that shown on the appliance (alternating current).

Given the diverse standards in effect, if the appliance is used in a country other than that in which it is purchased, have it checked by an approved service centre.
 This appliance is designed for domestic use only. In case of profes-

 This appliance is designed for domestic use only. In case of professional use, inappropriate use or failure to comply with the instructions, the manufacturer accepts no responsibility and the guarantee does not apply.

Connecting to the power supply

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been dropped or damaged in any manner. Return the appliance to your point of purchase.
 Do not use an extension lead. If you accept liability for doing so, only
- Do not use an extension lead. If you accept liability for doing so, only use an extension lead which is in good condition and is suited to the power of the appliance.
 If the power supply cord is damaged, it must be replaced by the manu-
- If the power supply cord is damaged, it must be replaced by the manu facturer. Return to your point of purchase. Do not take the appliance apart yourself.

Do not leave the cord hanging.

Do not unplug the appliance by pulling on the cord.

 Always unplug the appliance immediately after use; when moving it; prior to any cleaning or maintenance.

Using the appliance

 Use on a flat and stable, heat resistant work surface, away from any water splashes or any sources of heat.

When in operation, never leave the appliance unattended.

- This appliance is not designed to be used by people (including children)
 with a physical, sensory or mental impairment, or people without
 knowledge or experience, unless they are supervised or given prior instructions concerning the use of the appliance by someone responsible
 for their safety.
- Children must be supervised to ensure that they do not play with the appliance.
- This electrical appliance operates at high temperatures which may cause burns. Do not touch the hot surfaces of the appliance (lid, metal parts...).
- Do not switch on the appliance near flammable materials (blinds, curtains...) or close to an external heat source (gas stove, hot plate...etc.).
- In the event of fire, never try to extinguish the flames with water. Unplug the appliance. Close the lid, if it is not dangerous to do so. Smother the flames with a damp cloth.
- . Do not move the appliance when it is full of hot food.
- Never immerse the appliance in water!



Cooking

 This appliance is not suitable for recipes with a high-liquid content (eg. soups, cook-in sauces...).

Never turn on the appliance if the cooking pan is empty.

 Do not overfill the cooking pan, never exceed the indicated quantities or maximum food level mark (for chips only).

Description

- 1. Cool touch area of the lid
- 2. Transparent lid
- Latch for removing lid
- Measuring spoon (14ml)
- 5. Locking/unlocking paddle lever
- Maximum food level markers (for chips only)
- Removable mixing paddle
- 8. Non-stick removable cooking pan
- 9. Cooking pan handle release button

- 10. Cooking pan handle
- 11. Base
- Removable filter
- Lid opening buttons 14. Digital timer
- 15. On/Off switch
- Timer setting button
- 17. Removable control panel

(for access to the battery compartment only)

Quick introduction for use

Refore first use

- To remove the lid fig. 1, press the lid opening buttons (13) at the same time and lift the latch (3) to take off the lid fig. 2.
- Remove the measuring spoon.
- . Lift the handle to a horizontal position until you hear a "click" as it
- Take out the cooking pan fig. 3.
- To remove the paddle, lift up the light grey colour locking lever positioned on part of the paddle. Position your thumb on the top of the paddle and your index and middle finger under the locking lever, lift up the locking lever using your fingers to unlock the paddle – Tig. 4a. • All the removable parts are dishwasher safe – Tig. 5 or can be washed
- with a soft sponge and washing up liquid.

 Wipe the base of the appliance using a damp cloth and washing up
- liquid.
- Rinse and dry the parts carefully before putting them back together.
 To fit the paddle, pull the light grey colour locking lever up, then place the paddle in the middle of the cooking pan and push the locking lever
- down fig. 4b. During its first use, the appliance may give off a slight odour: this is not harmful and it will disappear quickly. It has no effect on the functioning. of your + ActiFry.

Remove all the stickers and any packaging.

Never immerse the base in water

On first use, to obtain the best results from your new product, we advise you to prepare a recipe that cooks for 30 minutes or more.

Preparing food

- Place the food in the cooking pan, distributing it evenly, making sure that
 you respect the maximum quantity (see cooking tables p. 17 to 19).
 Add the oil to the food with the spoon fig. 7, spreading it evenly (see
- cooking tables p. 17 to 19). (1 spoonful of oil = 14 ml of oil)
- Unlock the handle and fold it completely into its housing fig. 8.
 Close the lid fig. 9.

For chips, never exceed the maximum level indicated on the paddle - fig. 6. Do not leave the measuring spoon inside the pan when cooking food.

Cooking

Set the cooking time

- · Press the timer setting button to set the time. Hold down the button until desired time is featured on the display - fig. 10 (see cooking tables p. 17 to 19).
- Now release. The selected time (in minutes) is displayed and the countdown starts.
- If you make a mistake or to delete the selected time, hold down the button for 2 seconds then set the time again.

Be careful: the timer signals the end of the cooking but does not switch off the fryer.

Be careful: the timer signals the end of the cooking but does not switch off the fryer. Press the On/Off switch, the cooking begins thanks to the hot air circulation inside the cooking enclosure – fig. 11. The paddle rotates slowly in a clockwise direction.

Taking food out -

- \bullet Once cooking is completed, the timer beeps. To stop the beeping signal, press the timer setting button fig. 12, Press on On/Off to stop the appliance fig. 13 and open the lid. \bullet Lift the handle until you hear a "click" that it locks and take out the cooking pan fig. 14. \bullet Serve at once.

To avoid any risk of burns do not touch the lid or any part other than the cool touch area.

Table of cooking times

The cooking times below are only a guide and may vary according to the variety and batch of potatoes used. We recommend using varieties such as King Edward and Maris Piper for chips and potato recipes.

Potatoes -

| | TYPE | QUANTITY | OIL | COOKING TIME |
|---------------------------------|--|--------------------------------------|------------------|--------------|
| | Fresh | 1000 g* | 1 spoonful oil | 40 - 45 min |
| Chips standard thickness | Fresh | 750 g* | 3/4 spoonful oil | 35 - 37 min |
| 13mm x 13mm length up to 9cm | Fresh | 500 g* | 1/2 spoonful oil | 28 - 30 min |
| | Fresh | 250 g* | 1/4 spoonful oil | 24 - 26 min |
| D-t-t(tt) | Fresh | 1000 g* | 1 spoonful oil | 40 - 42 min |
| Potatoes (quartered) | Frozen | 750 g | None | 14 - 16 min |
| 5 | Fresh | 1000 g* | 1 spoonful oil | 40 - 42 min |
| Diced potato | Frozen | 750 g | None | 30 - 32 min |
| | Frozen - suitable for deep frying only | 750 g Standard 13mm x 13mm | None | 35 - 40 min |
| Chips | Frozen - 2 way or 3 way cook suitable | 750 g Thin 10mm x 10mm | None | 30 - 32 min |
| | for oven and grill (and deep frying). | 500 g American Style 8mm x 8mm | None | 25 - 27 min |

^{*}Weight of unpeeled potatoes

Other vegetables

| | | | | - 5 |
|---------------|--------------------|----------|------------------------------------|--------------|
| | TYPE | QUANTITY | OIL | COOKING TIME |
| Courgettes | Fresh, in slices | 750 g | 1 spoonful oil + 150 ml cold water | 25 - 35 min |
| Sweet peppers | Fresh, in slices | 650 g | 1 spoonful oil + 150 ml cold water | 20 - 25 min |
| Mushrooms | Fresh, in quarters | 650 g | 1 spoonful oil | 12 - 15 min |
| Tomatoes | Fresh, in quarters | 650 g | 1 spoonful oil + 150 ml cold water | 10 - 15 min |
| Onions | Fresh, in rings | 500 g | 1 spoonful oil | 15 - 25 min |

Meat - Poultry —

To add flavour to meat and poultry, mix some spices (such as paprika, curry, mixed herbs, thyme....) with the oil.

| | TYPF | OUANTITY | OII | COOKING TIME |
|----------------------------|--|------------------------------|----------------|--------------|
| | | , | | |
| | Fresh | 750 g | None | 18 - 20 min |
| Chicken nuggets | Frozen | 750 g | None | 18 - 20 min |
| | Frozen | 12 pieces (160 g) | None | 12 - 15 min |
| Chicken drumsticks | Fresh | 4 to 6 | None | 30 - 32 min |
| Chicken legs | Fresh | 2 | None | 30 - 35 min |
| Chicken breasts (boneless) | Fresh | 6 (about 750 g) | None | 10 - 15 min |
| Chinese Spring Rolls | Fresh | 4 to 8 small | 1 spoonful oil | 10 - 12 min |
| Lamb chops | Fresh (2.5 cm to 3 cm thick) | 2 to 6 | None | 20 - 25 min* |
| Pork chops | Fresh (2.5 cm to 3 cm thick) | 2 to 3 | None | 18 - 23 min* |
| Pork fillet | Fresh | 2 to 6 thin slices or strips | 1 spoonful oil | 12 - 15 min |
| Sausages | Fresh | 4 to 8 (pricked) | None | 10 - 12 min |
| Chilli Con Carne | Fresh (made from minced beef) | 500 g | 1 spoonful oil | 30 - 40 min |
| Beef steak | Fresh (rump or sirloin cut into 1 cm thick strips) | 600 g | None | 8 - 10 min |
| Meatballs | Fresh | 12 pieces | None | 18 - 20 min |

^{*}Turn halfway through cooking

---- Fish - Shellfish

| | TYPE | QUANTITY | OIL | COOKING TIME |
|-------------------|---------------------|-------------------|----------------|--------------|
| Breaded scampi | Frozen | 18 pieces (280 g) | None | 10 min |
| Monkfish | Fresh cut in pieces | 500 g | 1 spoonful oil | 20 - 22 min |
| Prawns | Cooked | 400 g | None | 10 - 12 min |
| Jumbo King prawns | Frozen and thawed | 300 g (16 pieces) | None | 12 - 14 min |

Desserts —

| | TYPE | QUANTITY | OIL | COOKING TIME |
|--------------|---|-------------------|--|--------------|
| Bananas | Cut in slices | 500 g (5 bananer) | 1 spoonful oil + 1 spoonful brown sugar | 4 - 6 min |
| | Wrapped in tinfoil | 2 bananas | None | 20 - 25 min |
| Cherries | Whole | Up to 1000 g | 1 spoonful oil + 1 to 2 spoonful sugar | 12 - 15 min |
| Strawberries | Cut in quarters if large or halves if small | Up to 1000 g | 1 to 2 spoonful sugar | 5 - 7 min |
| Apples | Cut in wedges | 3 | 1 spoonful oil + 2 spoonful sugar | 15 - 18 min |
| Pears | Cut in pieces | Up to 1000 g | 1 to 2 spoonful sugar | 8 - 12 min |
| Pineapple | Cut in pieces | 1 | 1 to 2 spoonful sugar | 8 - 12 min |

| | TYPE | QUANTITY | OIL | COOKING TIME |
|--------------------------|--------|-----------|------|--------------|
| Ratatouille | Frozen | 28 oz bag | None | 20 - 22 min |
| Pan-fried fish and pasta | Frozen | 28 oz bag | None | 20 - 22 min |
| Pasta carbonara | Frozen | 28 oz bag | None | 15 - 20 min |
| Paella | Frozen | 28 oz bag | None | 15 - 20 min |
| Cantonese rice | Frozen | 28 oz bag | None | 15 - 20 min |
| Chili con carne | Frozen | 28 oz bag | None | 12 - 15 min |

ActiFry cooking hints and tips

- . Do not add salt to chips while the chips are in the pan. Only add salt once the chips are removed from the appliance at the end of cooking.
- . When adding dried herbs and spices to Actifry, mix them with some oil or liquid. If you try sprinkling them directly into the pan they will just get blown around by the hot air system.
- Please note that strong coloured spices may slightly stain the paddle and parts of the appliance. This is normal.
- · For best results, use finely chopped garlic instead of crushed garlic to avoid it adhering to the central paddle.
- · If using onions in ActiFry recipes, they are best thinly sliced instead of chopped as they cook better. Separate the onion rings before adding them to the pan and give them a quick stir so that they are evenly
- . With meat and poultry dishes, stop the appliance and stir the pan once or twice during cooking so that the food on top does not dry out and the dish thickens evenly.
- Prepare vegetables in small pieces or stir fry size to ensure they cook through.
- This appliance is not suitable for recipes with a high-liquid content (eg. soups, cook-in sauces...).

Easy cleaning

Cleaning the appliance

- · Leave it to cool down completely before cleaning
- Open the lid fig. 1 and lift the latch to take off the lid fig. 2
- Lift the handle to the horizontal position until you hear a "click" as it locks - fig. 3.
- Take out the cooking pan.
- To remove the mixing paddle, lift up the locking lever fig. 4a.
 Remove the filter by pulling the top fig. 3 and wash it.
- All the removable parts are dishwasher safe fig. 5 or can be washed with a soft sponge and washing up liquid.

 • Clean the base of the appliance using a damp cloth and washing up
- Rinse and dry parts carefully before putting them back together.
- If food gets stuck or burnt on to the pan or paddle, leave them to soak in warm water before cleaning.
- The appliance has a non-stick cooking pan: the browning and scratches which may appear after long term use do not present any problems and are normal.
- We augrantee that the non-stick coating complies with regulations concerning materials in contact with foodstuffs.

Never immerse the base in water

Do not use harsh or abrasive cleaning products or scourers

The removable filter must be cleaned regularly.

To retain the non-stick qualities of the cooking pan for as long as possible, do not use metal utensils when serving food.

Environment protection first!

Timer battery

This appliance uses a button battery – L1154.

- To change the battery remove the control panel with a small flat bladed jewellers screw driver. Prise the control panel up by inserting the screwdriver into the gap at the top of the panel. Remove the white battery cover and replace the battery – fig. 15. To protect the environment do not throw the old battery in your regular waste but take it to a suitable collection point.
- Insert a new battery, put the battery cover back on and clip the control panel back on.
 - ① Your appliance contains valuable materials which can be recycled.
 - The square of th



If your fryer is not working correctly

| PROBLEMS | CAUSES | SOLUTIONS» | |
|---|--|---|--|
| The appliance is not working. | The appliance is not plugged in. | Check that the appliance is plugged in correctly. | |
| | The On-Off switch is not fully pressed down. | Press on the On/Off switch. | |
| | You have pressed down the On-Off switch but the appliance is not working. | Close the lid. | |
| | The motor is running but the appliance does not heat. | Contact your point of purchase. | |
| | The paddle does not turn. | Check that the paddle is correctly positioned. If the problem continues, contact your point of purchase. | |
| The removable paddle doesn't stay in place. | The mixing paddle is not locked. | Check that the locking lever has been pushed down fully. | |
| Food is not cooking evenly. | The paddle has not been installed. | Fit the paddle. | |
| | The food has not been cut in regular size pieces. | Cut food to the same size. | |
| | The chips have not been cut in regular size pieces. | Cut the chips to the same size. | |
| | The paddle has been installed correctly but it does not turn. | Check that it has been pushed down and clicked in position. If the problem continues, contact your point of purchase. | |
| The chips are not crispy enough. | The wrong variety of potatoes has been used. | Choose a variety of potato recommended for chips. | |
| | The potatoes are insufficiently washed and/ or not completely dried. | Wash the potatoes for a long time to remove excess starch, then drain and dry them before cooking. They must be completely dry. | |
| | The chips are too thick. | Cut the chips thinner. The maximum chips dimensions are 13mm x 13 mm. | |
| | There is not enough oil for the quantity of chips. | Increase the oil quantity (see cooking tables p. 17 to 19). | |
| | The filter is obstructed. | Clean the removable filter. | |
| The chips break up during the cooking. | The potatoes used are recently harvested and hence have a high water content. | Reduce the quantity of potatoes down to 800 g and adjust the cooking time. | |
| The food stays on the edge of the cooking pan. | The cooking pan is too full. | Respect the maximum quantities indicated in the cooking tables. | |
| Cooking liquids have flowed into the base of the appliance. | The paddle is not positioned correctly or the seal of the paddle is defective. | Make sure that the paddle is correctly positioned. If the problem continues, contact your point of purchase. Do not use ActiFry for making soups or recipes with a high liquid content. | |
| The timer does not work. | The battery is dead. | Change the battery (see fig. 15). | |
| The appliance is unusually noisy. | You suspect the motor is not working correctly. | Contact your point of purchase. | |
| The paddle stops turning during cooking. | The paddle is not positioned correctly. | Using an oven glove, push the paddle downward until it clicks into place. If this does not work, contact your point of purchase. | |

Ref: 5086507 Conception: www.batoteam.fr

